

# RAQ's by the Pallets

2510 Telegraph L-302, Bloomfield Hills, Michigan, 48302



## Products by the Pallet

All of our products can be shipped by the pallet, we offer the following options:

### **Distributor Starter Pallet:**

This is a pallet that contains 3 RAQ's, 1 RAQ's, Landscape RAQ's, Start Brackets, and will install approximately 100 solar panels

### **3 RAQ Pallet:**

This is a pallet that contains only 3 RAQ's

### **1 RAQ Pallet:**

This is a pallet that contains only 1 RAQ's

### **Start Bracket Pallet:**

This is a pallet that contains only Start Brackets

### **High Wind Zone Pallet:**


This is a pallet that contains only High Wind Zone Kits

### **60 or 72 Cell Landscape Pallet:**

This is a pallet that contains only landscape pallets



*Pallet details on each product can be found on the product specification sheets on our website: [www.solarrag.com](http://www.solarrag.com) "Installation Videos and training"*




*Each pallet contains different quantities of different products, and can be custom ordered to fit the needs of the installers.*



## SINGLE PICK PALLETS

We are pleased to present the FIRST SINGLE PICK process in the solar industry. Every RAQ is fitted with a small box that contains the LAG bolts, Flashing, and Zip ties needed for wire management. This means when a customer orders THE RAQ, your staff only needs to “PICK” from the pallet once, NO KITTING or tracking of individual small pieces

**1 RAQ, 3 RAQ,  
Landscape 60 cell  
Landscape 72 cell**




## Start Brackets & Wind Zone Kits


Start Brackets & Wind Zone Kits, can be stacked on the pallets for shipment, none of our pallets currently can be double stacked, the weights of our pallets are less than two tons

## Special Requests

We will do our best to accommodate any special requests by distributors for shipping and handling



# Pallet Weights and Measurements

	Description	# OF Panels/ Inverters	Quantity on Pallet	Length	Width	Height	Weight	Total Weight per Pallet
SR-10,000	1 Panel RAQ	60	60	48	48	24	1080	1284
	Flashing, Hardware		240				204	
SR-20,000	Starter Pallet	110		130	48	24		1853.70
	1 Panel	15	15				270	
	3 Panel	90	30				1320	
	60 Cell Landscape	5	5				100	
	Start Brackets	17					18.7	
	Flashing, Hardware		170				145	
SR-30,000	3 Panel RAQ	180	60	130	48	24	2220	2526
	Flashing, Hardware		360					
SR-40,000	Wind Zone Pallet		60	48	48	24	190	190
SR-50,000	Start Bracket Pallet		180				198	198
SR-60,000	60 Cell Landscape	60	60	92	48	24	1380	1584
	Flashing, Hardware		240			204		
SR-70,000	72 Cell Landscape	60	60	102	48	24	1560	1764
	Flashing, Hardware		240			204		
SR-90,000	Micro Inverter Pallet	180	60	48	48	47.5	1026.5	1026.5